

Kit Contents:

- Caravan bracket.
- U bolt with sledge and wing nuts.
- 2 x M6 BZP bolts.
- 2 x M6 lock nuts.
- 2 x M6 form C BZP washers.



Features:

- Ideal for mounting aerials on a caravan.
- Bolts to the A frame of the caravan allowing you to mount a pole to the U bolt on the other side.
- Sledge offers extra support.
- Wing nuts self-tighten by hand on the U bolt, while using a ratchet spanner (PROSPAN8-10) on the bolts is recommended.
- Suitable to mount poles up to 1" (25.4mm) outer diameter.
- Made from pregalvanised steel to prevent corrosion and give a professional finish.

Instructions:

1. Clamp the caravan bracket to the A frame, as shown, in a convenient position and tighten the 2 bolts and lock nuts.
2. The mast and aerial can now be fitted into position, as shown.
3. If possible, push the bottom end of the mast into the ground first to ensure stability.

