PROIRME4 Infra-Red Signal Extender Cable




This IR extender cable enables you to extend the operation of a DVD or STB type of equipment's infrared receiver to greater distance. This allows you to operate your video recorder, stereo system, receiver, etc. located behind the closed doors of a TV stand, A/V cabinet, or cupboard.



Connections:

- Connect the 5V input power source from the USB connector to the DC adapter (not supplied) or the TV USB port.
- 2. Position the Infra-Red Signal Transmitter on the IR pick-up window on your DVD video recorder; stereo system, receiver or STB, etc.
- 3. Point the existing correct remote control at the IR Receiver.



Specifications:

- Power Supply: The 5V input power source is supplied by DC Adapter or from the USB output of TV.
- Infra-Red Receiver: Receives the signal from the remote control IR signal of DVD/STB etc.
- Infra-Red Blaster: Transmits the IR signal to the relevant remote control.

sales@blake-uk.com www.blake-uk.com 0114 223 5000